

PIC Wire & Cable

Termination Instructions

T-11179

A Division of the Angelus Corporation
 Ph (262)-246-0500 Fax (262) 246-0450 www.picwire.com
 W220 N1051 Springdale Road, Waukesha, WI 53186

Approved : PFT
 Distribution : USER









Date : 03/11/21
 Rev 0
 Uncontrolled if Printed

Termination Instructions for PIC P/N 11179 - RJ45 PLUG WITH ATUM STRAIN RELIEF (for E6A5824 & E74824 ETHERNET CABLES)

Required Tooling :	PIC P/N 111184 Crimp Tool, Heat Gun
Recommended Hand Tools :	X-acto Knife, Sharp Razor, Wire Cutters, Locking Tab Heat Shield, Magnifier, Small Side Snips

- 1) Install Labels (if applicable), then install the 1" long piece of 12/3 ATUM.
 Make Cut A @ 0.760" from end of cable, through jacket only.
 DO NOT nick or cut into the braids. Remove the jacket (Fig. 1).
- 2) Flair and fold braid back over the jacket. Remove the foil shields close to Cut A to expose the twisted pairs (Fig. 2); verify insulation integrity.
- 3) Untwist each pair, for approximately half of the stripped length, carefully straighten each wire. Align wires into desired wire configuration per work print, and install wires into the load bar. NOTE: Load bar only fits within the connector in one orientation, see Figure 5. Use installed load bar to "comb" or work the wires into shape, until thoroughly straight for approximately half the cut length, while maintaining pairs' twist close to Cut A. Set far edge of load bar at .680" and trim conductors flush (Fig. 3).
- 4) Bend the connector strain relief tabs open, to allow entry for load bar (Fig. 4). Install wires the connector body, keeping alignment intact (Fig. 5).
- 5) To complete full insertion, push while lightly wiggling the cable to help the conductors slide into their channels. Proper insertion is indicated by viewing ALL of the wire conductors through the front end of the connector body. Use Magnifier if needed (Fig. 6).
- 6) Bend the strain relief tab to align with the cable, careful to keep the braid strands enclosed. Lightly bend the ends of the strain relief tabs in to prep for crimping (Fig. 7).
- 7) Verify full insertion before crimping the connector. Crimp using PIC P/N 111184 crimp tool. Trim any braids past the end of the crimped strain relief tab (Fig 8).
- 8) Bring the ATUM 12/3 x 1.0" over the shoulder of the connector, and shrink onto the connector at the retention clips and cable (Fig. 9), while taking care to shield the RJ45 latching tab from excessive heat. Verify full travel of the latching tab, trim back shrink tube if it impedes the latching tab (Fig. 9).

All Dimensions in inches - Not to Scale



Pin	568A Configuration	568B Configuration
1	White / Green	White / Orange
2	Green	Orange
3	White / Orange	White / Green
4	Blue	Blue
5	White / Blue	White / Blue
6	Orange	Green
7	White / Brown	White / Brown
8	Brown	Brown